

AD Enclosure - Pbar Transport

Search and Secure Procedure

Pbar Transport
PbarTrans.V1.0



- 0) You will need to check the Transport area C-Blocks in AP0, verify that the chains are in place and locked with 2 padlocks. Bring AP0 keys.
- 1) "A" and "B" enters the Transport enclosure from the downstream end of AP0.
 - 2) "A" and "B" resets Interlock Box #1 at entrance at top of stairwell.
 - 3) "A" holds while "B" checks the upstream section.
 - 4) "A" and "B" sweep the enclosure to the "Y".
 - 5) "A" holds while "B" sweep the area to reset Interlock Box #2.
 - 6) "B" then sweeps the area to reset Interlock Box #3.
 - 7) "B" joins "A" and they Control Access out of the Enclosure

| | |
|----------------------------|--------|
| Reviewed AD/RSO | Date |
| <i>Michael A. Gerardi</i> | 4-1-09 |
| Approved AD/OPS Dept. Head | Date |
| <i>[Signature]</i> | 4-2-09 |

spb 17 Dec 2007
Version 1.0

CONTROLLED DOCUMENT

Users are responsible for ensuring they work to the latest approved revision. Printed or electronically transmitted copies are uncontrolled.